

by Thor's Drone World

User's Manual

Content:

Utility mount

Aluminum body

Spare Screw M3x10 (x2)



Compatible with 7.9" up to

washer

wrench key

Hex Key / Allen Key (x2)

Star knob thumbscrew (1/4"-20x1/2")

How to assemble:



Using the provided small hex key remove the screws to dismount the top aluminum plate from the main body.



Once the controller is in place align the utility mount's plate and pre-screw all **4** screws back by hand.









Use the wrench key and big hex key provided to adjust the angle of the utility mount to your preferred position.

The clamp has two mechanisms to ensure your tablet sit secure and in place.

The first mechanism is the ratchet part, to adjust to the size of your tablet. We recommend setting it a little smaller (1" / 2.5cm) than the actual size of the table for a tighter, secure fit.

Once you have selected the right height lock the ratchet in place by sliding the lock downwards.



Place the tablet in landscape mode by pulling the spring mechanism upwards and release it to secure the tablet in place. You can adjust the top clamp brackets, if needed, to avoid pressing on any **buttons**





Compatible with most small tablets like 7.9" iPad Mini or similar up to larger tablets like the iPad Pro 12.9"

Max. thickness 20mm



Separately sold

accessories:



Feed Cables



Monitor

Sun hoods



www.lifthor.com

